Honeywell Sensing and Productivity Solutions

□□□□□□□□□□□□□ □□□□□□□□□ □□□□ □□□□□□□□□□□□□□□□. □□□□□□□ □□□□□□□□□ □□□□□□□□□□ □□□□□□□□□.

2450CM 86210191

□□□□□□ □□□□□□:	2450CM 86210191
□□□□□□□□□□□ / □□□□□□□:	Honeywell Sensing and Productivity Solutions
□□□□□□□□ □□□□□□	MANUAL RESET THERMOSTAT
□□□□□□□□□ □□□□□□:	1.2450CM 86210191.pdf 2.2450CM 86210191.pdf
RoHs □□□□□□□	□□□□□□□ □□□□□ / RoHS Compliant
□□□□□□□	□□□□ □□□□□
□□□□□□□□□□ □□□	DHL/Fedex/TNT/UPS/EMS

□□□□□□□□□ □□□□□□□□□

□□□□□□□□□□□□□□□ 2450CM 86210191

□□□□□□ □□□□□□	2450CM 86210191
□□□□□□□□□□□	Honeywell Sensing and Productivity Solutions
□□□□□□	MANUAL RESET THERMOSTAT
□□□□□□□ □□□□□□□□□□ □□□□□□□ / ROHS □□□□□□□	□□□□□□□ □□□□□ / RoHS Compliant
□□□□□□□□□ □□□□□□□	1.2450CM 86210191.pdf 2.2450CM 86210191.pdf
□□□□□□□□□□□	-
□□□□□□□□□ □□□□□	Screw Terminal
□□□□□□□□□□□□ □□□□□□□□	485°F (251.7°C)
□□□□□□□□ □□□□□□□	6K
□□□□□	2450CM
□□□□□□□□□□□□ □□□□□□	Manual Reset
□□□□□□ / □□□□□	Module
□□□□ □□□□□□□□	2450CM86210191
□□□□□□□□□ □□□□	Chassis Mount
□□□□□□□□□□ □□□□□□□□□□□□□ □□□□ (MSL)	1 (Unlimited)
□□□□□□□□□□□ □□□□□□□□□□□ □□□□□□□□ □□□	13 Weeks
□□□□□□□ □□□□□□□□□□ □□□□□□□ / ROHS □□□□□□□	Lead free / RoHS Compliant
□□□□□□□□□ □□□□□□□□ - DC	-
□□□□□□□□□ □□□□□□□□ - AC	10A (240V), 15A (120V)
□□□	SPST-NC

□□□□□□□□□□□□□□□

Tags

Honeywell Sensing and Productivity Solutions 2450CM 86210191	2450CM 86210191 □□□□□□□□□□□□	2450CM 86210191 □□□□□□□□□□□
2450CM 86210191 □□□□	2450CM 86210191 □□□□□□□□	2450CM 86210191 □□□□□□
2450CM 86210191 PDF □□□□□□□□□ □□□□□□	2450CM 86210191 □□□□□□□□□□□ □□□□□□□□□ □□□□□□	2450CM 86210191 □□□□□□□□□ □□□□□□
2450CM 86210191 □□□□□□□	□□□□□□□□ 2450CM 86210191	□□□□□□□□ Honeywell Sensing and Productivity Solutions 2450CM 86210191
Honeywell Sensing and Productivity Solutions 2450CM 86210191	Honeywell Sensing and Productivity Solutions □□□□□□□□□□□	Honeywell Sensing and Productivity Solutions □□□□□□□□□□□□
Honeywell Sensing and Productivity Solutions 2450CM 86210191	HONEYWELL 2450CM 86210191	Honeywell Sensing and Control EMEA 2450CM 86210191
Honeywell Sensing and Productivity Solutions T&M 2450CM 86210191		

□□□□□□□ □□□□□□□□□□□

2450CM-79130484
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□□□□□□□□: Out stock
RFQ

2450CM 82140044
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□□□□□□□□: Out stock
RFQ

2450CM 86890007
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□□□□□□□□: Out stock
RFQ

2450CM 85170010
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□□□□□□□□: Out stock
RFQ

2450CM 82090117
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□□□□□□□□: Out stock
RFQ

2450CM-90140922
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□□□□□□□□: Out stock
RFQ

2450CM 83250021
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□□□□□□□□: Out stock
RFQ

2450CM-71001003
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□□□□□□□□: Out stock
RFQ

2450CM 84210015
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□□□□□□□□: 73 pcs
RFQ

2450CM 86750001
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□□□□□□□□: Out stock
RFQ

2450CM 86750003
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□□□□□□□□: 43 pcs
RFQ

2450CM 82090123
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□□□□□□□□: Out stock
RFQ

□□□□□□□□ □□□□□□□□ © 2020 □□□□□□□□□□□ □□□□□□□□□□□□□ □□□□□ □□□□□□□□□□□□ - Ocean-Components.com
□□.□□□□□: Info@Ocean-Components.com
□□□□□□□□□: Room 2102, Connaught Commercial Building, 185 Wan Chai Rd, Wan Chai, Hong Kong