Honeywell | Honeywell Sensing and Productivity Solutions

2450CM 86890007

□□□□□□ □□□□□□:	2450CM 86890007
□□□□□□□□□□□ / □□□□□□:	Honeywell Sensing and Productivity Solutions
□■■■■■■■■ ■■■■■■	MANUAL RESET THERMOSTAT
□□□□□□□□□ □□□□□□:	1.2450CM 86890007.pdf 2.2450CM 86890007.pdf
RoHs □□□□□□□	□□□□□□□ □□□□□ / RoHS Compliant
□□□□□□□	□□□□ □□□□□
□□□□□□□□□□ □□□	DHL/Fedex/TNT/UPS/EMS

□□□□□□□□ □□□□□□□□□

□□□□□□□□□□□□ □□□□□□□□ □□□□ □□□□□□□□□□□□□□□. □□□□□□ □□□□□□□□ □□□□□□□□□ □□□□□□□□□.

□□□□□□□□□□□□□□ 2450CM 86890007

□□□□□□ □□□□□□	2450CM 86890007
□□□□□□□□□□□	Honeywell Sensing and Productivity Solutions
□□□□□□	MANUAL RESET THERMOSTAT
□□□□□□□ □□□□□□□□□□ □□□□□□□ / ROHS □□□□□□□	□□□□□□□ □□□□□ / RoHS Compliant
□□□□□□□□□ □□□□□□□	1.2450CM 86890007.pdf 2.2450CM 86890007.pdf
□□□□□□□□□□□	-
□□□□□□□□□ □□□□□	Screw Terminal
□□□□□□□□□□□□ □□□□□□□□	-
□□□□□□□□ □□□□□□□	6K
□□□□□	2450CM
□□□□□□□□□□□□ □□□□□□	Manual Reset
□□□□□□ / □□□□□	Module
□■■■ ■■■■■■■■	2450CM86890007
□□□□□□□□□ □□□□	Chassis Mount
□□□□□□□□□□ □□□□□□□□□□□□□ □□□□ (MSL)	1 (Unlimited)
□□□□□□□□□□□ □□□□□□□□□□□ □□□□□□□□ □□□	11 Weeks
□□□□□□□ □□□□□□□□□□ □□□□□□□ / ROHS □□□□□□□	Lead free / RoHS Compliant
□□□□□□□□□ □□□□□□□□ - DC	-
□□□□□□□□□ □□□□□□□□ - AC	10A (240V), 15A (120V)
□□□	SPST-NC

□□□□□□□□□□□□□□

Tags

Honeywell Sensing and Productivity Solutions 2450CM 86890007	2450CM 86890007 □□□□□□□□□□□□	2450CM 86890007 □□□□□□□□□□□
2450CM 86890007 □□□□	2450CM 86890007 □□□□□□□□	2450CM 86890007 □□□□□□
2450CM 86890007 PDF □□□□□□□□□ □□□□□□	2450CM 86890007 □□□□□□□□□□□ □□□□□□□□□ □□□□□□	2450CM 86890007 □□□□□□□□□ □□□□□□
2450CM 86890007 □□□□□□□	□□□□□□□□ 2450CM 86890007	□□□□□□□□ Honeywell Sensing and Productivity Solutions 2450CM 86890007
Honeywell Sensing and Productivity Solutions 2450CM 86890007	Honeywell Sensing and Productivity Solutions □□□□□□□□□□□	Honeywell Sensing and Productivity Solutions □□□□□□□□□□□□
Honeywell Sensing and Productivity Solutions 2450CM 86890007	HONEYWELL 2450CM 86890007	Honeywell Sensing and Control EMEA 2450CM 86890007
Honeywell Sensing and Productivity Solutions T&M 2450CM 86890007		

□□□□□□□ □□□□□□□□□□

2450CM 85170010
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM-98580005
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM-90140922
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM-90820203
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM 86210191
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM 83250021
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM-71001003
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CMG80020680
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM 86750001
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM 84210015
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: 73 pcs
RFQ

2450CM-79130484
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM 86750003
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: 43 pcs
RFQ

□□□□□□□□ □□□□□□□□ © 2020 □□□□□□□□□□□ □□□□□□□□□□□□□ □□□□□ □□□□□□□□□□□□ - Ocean-Components.com
□□.□□□□□: Info@Ocean-Components.com
□□□□□□□□□: Room 2102, Connaught Commercial Building, 185 Wan Chai Rd, Wan Chai, Hong Kong