Honeywell | Honeywell Sensing and Productivity Solutions

Honeywell

2450CM-90820203

□□□□□□ □□□□□□: 2450CM-90820203

□□□□□□□□□□□ / □□□□□□: Honeywell Sensing and Productivity Solutions

□■■■■■■■■ ■■■■■■: MANUAL RESET THERMOSTAT

□□□□□□□□□ □□□□□□: 1.2450CM-90820203.pdf, 2.2450CM-90820203.pdf

RoHs □□□□□□□: □□□□□□□ □□□□□ / RoHS Compliant

□□□□□□□: □□□□ □□□□□

□□□□□□□□□□ □□□: DHL/Fedex/TNT/UPS/EMS

□□□□□□□□□□□□ □□□□□□□□ □□□□ □□□□□□□□□□□□□□□□. □□□□□□ □□□□□□□□ □□□□□□□□□□ □□□□□□□□□.

□□□□□□□□□□□□□□□ 2450CM-90820203

□□□□□□ □□□□□□	2450CM-90820203
□□□□□□□□□□□	Honeywell Sensing and Productivity Solutions
□□□□□□	MANUAL RESET THERMOSTAT
□□□□□□□ □□□□□□□□□□ □□□□□□□ / ROHS □□□□□□□	□□□□□□□ □□□□□ / RoHS Compliant
□□□□□□□□□ □□□□□□□	1.2450CM-90820203.pdf, 2.2450CM-90820203.pdf
□□□□□□□□□□□	-
□□□□□□□□□ □□□□□	Screw Terminal
□□□□□□□□□□□□ □□□□□□□□	-
□□□□□□□□ □□□□□□□	6K
□□□□□	2450CM
□□□□□□□□□□□□ □□□□□□	Manual Reset
□□□□□□ / □□□□□	Module
□□□□□□□□ □□□□	Chassis Mount
□□□□□□□□□ □□□□□□□□□□□□□ □□□□ (MSL)	1 (Unlimited)
□□□□□□□□□□ □□□□□□□□□□□ □□□□□□□□ □□□	18 Weeks
□□□□□□□ □□□□□□□□□□ □□□□□□□ / ROHS □□□□□□□	Lead free / RoHS Compliant
□□□□□□□□□ □□□□□□□□ - DC	-
□□□□□□□□□ □□□□□□□□ - AC	10A (240V), 15A (120V)
□□□	SPST-NC

□□□□□□□□□□□□□

Tags

- Honeywell Sensing and Productivity Solutions 2450CM-90820203
- 2450CM-90820203 □□□□□□□□□□□
- 2450CM-90820203 □□□□□□□□□□
- 2450CM-90820203 □□□□
- 2450CM-90820203 □□□□□□□
- 2450CM-90820203 □□□□□□
- 2450CM-90820203 PDF □□□□□□□□□ □□□□□□
- 2450CM-90820203 □□□□□□□□□□ □□□□□□□□□ □□□□□□
- 2450CM-90820203 □□□□□□□□ □□□□□□
- 2450CM-90820203 □□□□□□□
- □□□□□□□ 2450CM-90820203
- □□□□□□□ Honeywell Sensing and Productivity Solutions 2450CM-90820203
- Honeywell Sensing and Productivity Solutions 2450CM-90820203
- Honeywell Sensing and Productivity Solutions □□□□□□□□□□□
- Honeywell Sensing and Productivity Solutions □□□□□□□□□□□
- Honeywell Sensing and Productivity Solutions 2450CM-90820203
- HONEYWELL 2450CM-90820203
- Honeywell Sensing and Control EMEA 2450CM-90820203
- Honeywell Sensing and Productivity Solutions T&M 2450CM-90820203

□□□□□□□ □□□□□□□□□□

2450CMG80750343
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM-90140922
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CMG80020680
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM 86890007
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM-71001003
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CMG80890028
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM 86750001
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CMG81000405
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM 86750003
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: 43 pcs
RFQ

2450CM-79130484
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CMG81840032
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

2450CM-98580005
□□□□□□□□□□□□: Honeywell Sensing and Productivity
□□□□□□: MANUAL RESET THERMOSTAT
□■■■■■■■: Out stock
RFQ

□□.□□□□□: Info@Ocean-Components.com

□□□□□□□□□: Room 2102, Connaught Commercial Building, 185 Wan Chai Rd, Wan Chai, Hong Kong