Honeywell | Honeywell Sensing and Productivity Solutions

Honeywell

2450CM-79130484

□□□□□□ □□□□□□: 2450CM-79130484

□□□□□□□□□□□ / □□□□□□: Honeywell Sensing and Productivity Solutions

□■■■■■■■■ ■■■■■■: MANUAL RESET THERMOSTAT

□□□□□□□□□ □□□□□□: 1.2450CM-79130484.pdf, 2.2450CM-79130484.pdf

RoHs □□□□□□□: □□□□□□□ □□□□□ / RoHS Compliant

□□□□□□□: □□□□ □□□□□

□□□□□□□□□□ □□□: DHL/Fedex/TNT/UPS/EMS

□□□□□□□□ □□□□□□□□

□□□□□□□□□□□□ □□□□□□□□ □□□□ □□□□□□□□□□□□□□□□. □□□□□□ □□□□□□□□ □□□□□□□□□□ □□□□□□□□□.

□□□□□□□□□□□□□□ 2450CM-79130484

□□□□□□ □□□□□□	2450CM-79130484
□□□□□□□□□□□	Honeywell Sensing and Productivity Solutions
□□□□□□	MANUAL RESET THERMOSTAT
□□□□□□□ □□□□□□□□□□ □□□□□□□ / ROHS □□□□□□□	□□□□□□□ □□□□□ / RoHS Compliant
□□□□□□□□□ □□□□□□□	1.2450CM-79130484.pdf 2.2450CM-79130484.pdf
□□□□□□□□□□□	-
□□□□□□□□□ □□□□□	Screw Terminal
□□□□□□□□□□□□ □□□□□□□□	-
□□□□□□□□ □□□□□□□	6K
□□□□□	2450CM
□□□□□□□□□□□□ □□□□□□	Manual Reset
□□□□□□ / □□□□□	Module
□□□□□□□□□ □□□□	Chassis Mount
□□□□□□□□□□ □□□□□□□□□□□□□□ □□□□ (MSL)	1 (Unlimited)
□□□□□□□ □□□□□□□□□□ □□□□□□□ / ROHS □□□□□□□	Lead free / RoHS Compliant
□□□□□□□□□ □□□□□□□□□ - DC	-
□□□□□□□□□ □□□□□□□□□ - AC	10A (240V), 15A (120V)
□□□	SPST-NC

□□□□□□□□□□□□□□

Tags

- Honeywell Sensing and Productivity Solutions 2450CM-79130484
- 2450CM-79130484 □□□□□□□□□□□□
- 2450CM-79130484 □□□□□□□□□□□□
- 2450CM-79130484 □□□□
- 2450CM-79130484 □□□□□□□□
- 2450CM-79130484 □□□□□□
- 2450CM-79130484 PDF □□□□□□□□□ □□□□□□□
- 2450CM-79130484 □□□□□□□□□□□ □□□□□□□□□□ □□□□□□
- 2450CM-79130484 □□□□□□□□□ □□□□□□
- 2450CM-79130484 □□□□□□□
- □□□□□□□□ 2450CM-79130484
- □□□□□□□□ Honeywell Sensing and Productivity Solutions 2450CM-79130484
- Honeywell Sensing and Productivity Solutions 2450CM-79130484
- Honeywell Sensing and Productivity Solutions □□□□□□□□□□□□
- Honeywell Sensing and Productivity Solutions □□□□□□□□□□□□□
- Honeywell Sensing and Productivity Solutions 2450CM-79130484
- HONEYWELL 2450CM-79130484
- Honeywell Sensing and Control EMEA 2450CM-79130484
- Honeywell Sensing and Productivity Solutions T&M 2450CM-79130484

□□□□□□□ □□□□□□□□□□

Honeywell

2450CM-90820203

□□□□□□□□□□□□: Honeywell Sensing and Productivity

□□□□□□: MANUAL RESET THERMOSTAT

□■■■■■■■: Out stock

RFQ

Honeywell

2450CM-71001003

□□□□□□□□□□□□: Honeywell Sensing and Productivity

□□□□□□: MANUAL RESET THERMOSTAT

□■■■■■■■: Out stock

RFQ

Honeywell

2450CM 85170010

□□□□□□□□□□□□: Honeywell Sensing and Productivity

□□□□□□: MANUAL RESET THERMOSTAT

□■■■■■■■: Out stock

RFQ

Honeywell

2450CM 86890007

□□□□□□□□□□□□: Honeywell Sensing and Productivity

□□□□□□: MANUAL RESET THERMOSTAT

□■■■■■■■: Out stock

RFQ

Honeywell

2450CMG80890028

□□□□□□□□□□□□: Honeywell Sensing and Productivity

□□□□□□: MANUAL RESET THERMOSTAT

□■■■■■■■: Out stock

RFQ

Honeywell

2450CM-98580005

□□□□□□□□□□□□: Honeywell Sensing and Productivity

□□□□□□: MANUAL RESET THERMOSTAT

□■■■■■■■: Out stock

RFQ

2450CM 86750003

□□□□□□□□□□□□: Honeywell Sensing and Productivity

□□□□□□: MANUAL RESET THERMOSTAT

□■■■■■■■: 43 pcs

RFQ

Honeywell

2450CM-90140922

□□□□□□□□□□□□: Honeywell Sensing and Productivity

□□□□□□: MANUAL RESET THERMOSTAT

□■■■■■■■: Out stock

RFQ

Honeywell

2450CM 86750001

□□□□□□□□□□□□: Honeywell Sensing and Productivity

□□□□□□: MANUAL RESET THERMOSTAT

□■■■■■■■: Out stock

RFQ

Honeywell

2450CM 86210191

□□□□□□□□□□□□: Honeywell Sensing and Productivity

□□□□□□: MANUAL RESET THERMOSTAT

□■■■■■■■: Out stock

RFQ

Honeywell

2450CMG80020680

□□□□□□□□□□□□: Honeywell Sensing and Productivity

□□□□□□: MANUAL RESET THERMOSTAT

□■■■■■■■: Out stock

RFQ

Honeywell

2450CMG80750343

□□□□□□□□□□□□: Honeywell Sensing and Productivity

□□□□□□: MANUAL RESET THERMOSTAT

□■■■■■■■: Out stock

RFQ

□□□□□□□□ □□□□□□□□ © 2020 □□□□□□□□□□□ □□□□□□□□□□□□□ □□□□□ □□□□□□□□□□□□□ - Ocean-Components.com

□□.□□□□□: Info@Ocean-Components.com

□□□□□□□□□: Room 2102, Connaught Commercial Building, 185 Wan Chai Rd, Wan Chai, Hong Kong